




ASSEMBLY INSTRUCTION

SONOMA BOOKCASE 210CM




30 min



A x 30		M6 x 15
B x 2		M6 x 35
C x 1		Allen key M4


A x 20		M6 x 15
C x 1		Allen key M4

STEP 1




B x 2		M6 x 35
C x 1		Allen key M4


STEP 2




A x 10		M6 x 15
C x 1		Allen key M4

STEP 3




D x 4		Ø4 x 40
E x 4		Ø4 x 40
F x 2		


STEP 4



G x 2



STEP 5



G

