



ASSEMBLY INSTRUCTIONS - COFFEE TABLE

- ①  x8
M6 x 70mm
- ②  x8
M6
- ③  x8
M6
- ④  x1
M4



Ⓐ




x1




Ⓑ

x4


STEP 1



STEP 2



STEP 3



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

WARNINGS

- Dispose of all packing carefully and responsibly.
- Place product on an even surface prior to using.
- Suitable for Domestic Garden use only.
- Children should not be left alone in situ with product, please refrain children climbing onto the product.
- Frequently check any damage to the product including the underside and tighten fixings where required.
- Please use appropriate furniture covers when not in use. With all product, it must be protected from the elements. If it is left in sunlight without covering, it will begin to fade in colour. Please make sure to remove all debris / dirt before covering.
- In order to prolong the life of your product, we recommend it be stored in a dry and protected area during off season periods.
- Do not use a pressure washer to clean your product.

Self Assembly Items

- Check you have all the components and tools listed before assembly.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the parts during assembly, this could cause damage.
- Assemble on a soft level surface to avoid damaging the unit or your floor.

Material Specific

Sofas

- Do not sit on arm or back rest ledges.

CARE/CLEANING

General

- Do not use any abrasive substances which may scratch the surface.
- Remove all debris / dirt with soft bristle brush / cloth, use a clean cloth to wipe clean any problem areas. For thorough cleaning, use a mild soap and warm water, apply with a micro fibre cloth (no abrasive materials), wipe clean and let dry.

Timber

- Give your hardwood furniture a yearly scrub with soapy water, followed by a thorough rinse. This removes algae and pollution to restore the timber's surface, keeping it in good condition.
- To preserve the appearance of your timber, we recommend using a Hardwood Garden Furniture oil periodically.